



SW-MOTECH GmbH & Co. KG
BAGS-CONNECTION GmbH & Co. KG
Ernteweg 8/10 · 35282 Rauschenberg
Germany

Tel. +49 6425 8168-050
Fax +49 6425 8168-10
info@sw-bc.com
www.sw-bc.com

Gepäcksysteme
Navigation
Ergonomie
Sicherheit
Wartung

Weitere Produkte und Modellzuweisungen: www.sw-bc.com
More products and application lists: www.sw-bc.com

DUCATI

Multistrada

1200/S



DUCATI Multistrada 1200/S



- QUICK-LOCK EVO Tankring. Schwarz. Black. / (10-) ⊗ TRT.00.640.12600/B
- Schutzbügel. Schwarz. Crashbar. Black. / (10-) ⊗ SBL.22.142.10000/B
- Fußrasten-Kit. Silber. Footrest Kit. Silver. / (10-) ⊕ FRS.22.011.10000/S
- 1** QUICK-LOCK EVO Kofferträger. Schwarz. QUICK-LOCK EVO Side Carrier. Black. / (10-) ⊗ KFT.22.140.20000/B
- Spiegelverlängerung. Schwarz. Mirror Extension. Black. / (10-) ⊕ SVL.22.504.10000/B
- Lenkererhöhung. Schwarz. Bar Riser. Black. / (10-) ⊕ LEH.22.039.10000/B
- Hecktasche Drybag M. Schwarz. Tailbag Drybag M. Black. / (10-) ⊗ BCK.HTA.00.053.100
- 2** Motorschutz. Silber. Engine Guard. Silver. / (10-) ⊗ MSS.22.143.10000/S
- 3** QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS-Mount. Black. / (10-) ⊗ GPS.22.646.10000/B
- 4** Handprotektorenschutzbügel-Kit. Schwarz. Handguard Security Bar Kit. Black. / (10-) ⊗ HPR.00.133.20000/B
- Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. / (10-) ⊗ BCK.HTA.00.053.100/Y
- AERO ABS-Seitenkoffersystem. Schwarz. AERO ABS Sidecase System. Black. / (10-) ⊗ KFT.22.140.60000/B
- 5** QUICK-LOCK EVO Engage. Schwarz. Black. / (10-) ⊗ BC.TRS.00.107.20000
- QUICK-LOCK EVO Trial. Schwarz. Black. / (10-) ⊗ BC.TRS.00.102.20000

- QUICK-LOCK EVO Daypack. Schwarz. Black. / (10-) ⊗ BC.TRS.00.108.20000
- QUICK-LOCK EVO Micro. Schwarz. Black. / (10-) ⊗ BC.TRS.00.110.20000
- Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. / (10-) ⊗ BC.HTA.00.301.10000
- Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. / (10-) ⊗ BC.HTA.00.304.10000
- Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. / (10-) ⊗ BC.HTA.00.306.10000
- Hecktasche Jet Pack. Schwarz. Tailbag Jet Pack. Black. / (10-) ⊗ BC.HTA.00.303.10000
- Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. / (10-) ⊗ BC.HTA.00.307.10000
- QUICK-LOCK Kontur-Kofferträger. Schwarz. QUICK-LOCK Profile Side Carrier. Black. / (10-) ⊗ KFT.22.140.15000/B
- 6** Hauptständer. Schwarz. Centerstand. Black. / (10-) ⊕ HPS.22.141.10001/B
- HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. / (10-) ⊗ NSW.22.004.10001/B
- STEEL-RACK. Schwarz. Black. / (10-) ⊗ GPT.22.139.20001/B
- ALU-RACK. Schwarz. Black. / (10-) ⊗ GPT.22.139.15000/B

⊕ Mit ABE. TÜV-certified. ⊗ ABE nicht erforderlich. TÜV not required.

